



Installation Instructions for Alba Pro Elite 400EX Nerf Bars

1. (See Pic 1) Use the chrome mount bar, 2 chrome clamps and 2 bolts to loosely mount to the lower frame forward of the v shape. Do not tighten bolts yet.



2. Cut off the plastic heel guard as shown in pic 2. Unbolt the piece that is left attached to the footpeg. Repeat for the other side.



3. Slide the left nerf bar front on to the chrome mount bar. Line up the outside hole on the rear nerf mount tab with the hole on the foot peg (the one that the bolt came out of from the plastic footguard piece). Insert the bolt and nut snugly, but do not tighten. Repeat this same process for the right side nerf.
-

ALBA

RACING



4. See pic 3 Now drill a 3/8" hole thru the foot peg using the nerf bracket mount hole as a guide (one on each side). Install bolt and nut on each side.
5. Tighten all bolts and nuts. Re-check all of them for tightness. Also check that all bolts are tight after the first ride.
6. install nerf nets per illustration.

