



## WILDCAT GRAB BAR INSTALLATION

### TOOLS NEEDED

1 ½" HOLE SAW

7/16" OPEN END WRENCH (RATCHETING TYPE IS BEST)

T30 TORX WRENCH (OR BIT) There is one in the factory tool kit.

- 1) Use the supplied template to mark the hole to drill. The top of the paper will rest against the bottom lip of the logo panel on the glove box door. Line up the two outside lines with the outer corners of the logo panel. **(See pic 1)** Use a sharp pointed instrument to mark the plastic where it is noted on the template. Remove the template. Use a 1 ½" hole saw and drill a hole thru the dash. When done you can use sandpaper to clean the edges of the hole.
- 2) Look under the hood on the passenger side and locate the gold colored torx screw that mounts the oil cooler. Remove this screw – **don't lose it**. Grab the black metal grab bar receiver tube and insert the front of it (has the plastic receiver in the end) thru the back of the dash. ( It will be above the cross brace frame tube). The rear bracket will go under the cooler mount bracket and line up with the cooler mount hole. Be sure it is on the outside of the cooler mount **(See pic 2)**
- 3) Push the supplied U bolt around the front cross brace and slide it in to the 2 holes on the receiver tube front mount plate. Install a flat washer and nut on the U bolt (both ends). Do not tighten.
- 4) Install the torx screw thru the rear bracket and the oil cooler bracket. Tighten it.
- 5) Look at the front tube where it goes thru the dash. Center it and then tighten the 2 nuts on the U bolt. NOTE: If you need to adjust the tube up or down to fit the hole better you can bend the back of the tube(it will bend the mount tab) move it up or down depending on which way you need to adjust.
- 6) Insert the grab handle and line up the holes in the tube. Push the pin clip thru the holes and lock it. To adjust the handle for passenger comfort you can pull out on the handle and line up the holes to insert the pin clip. **(See pic 3)**
- 7) **CHECK ALL NUTS AND BOLTS FOR TIGHTNESS BEFORE USING.**
- 8) **CHECK TO MAKE SURE THE OILD LINE FROM THE OIL COOLER IS NOT KINKED.**

**PLEASE NOTE—WHEN DRIVING YOUR WILDCAT, MAKE SURE TO ALWAYS WEAR YOUR SEATBELT! FAILURE TO WEAR YOU SEAT BELT MAY RESULT IN SEVERE INJURY OR DEATH. IT IS ABSOLUTELY NECESSARY TO WEAR YOUR SEATBELT AT ALL TIMES. IN THE EVENT OF ANY TYPE OF IMPACT, ACCIDENT, ETC. THE SEAT RESTRAINTS WILL KEEP YOU AWAY FROM THE GRAB BAR.**



PIC 1



PIC 2



PIC 3