RZR 1000 DOOR MOUNTING INSTRUCTIONS

Parts included in kit: 4 panels, 6 black clips, 6 #10 Allen screws, 12 ¼-20 Allen screws

Tools needed: # T25 torx bit, 5/32 Allen wrench, 1/8 Allen wrench, light duty threadlock

1. Unpack the 4 panels being careful not to scratch the panels.
2. Remove the stock plastic door panels using the T25 torx bit.
3. Remove both seats.
4. *Mount the left and right side Alba door panels: Use 6 ¼" Allen screws per side. Put light duty threadlock on each screw. Install all the screws before you tighten them. Once they are all in go ahead and tighten them.* ==DO NOT OVERTIGHTEN THEM==. *If you use too much torque the nutserts in the fiberglass may spin.*
5. Now install the rear panels. Each panel will use 3 clips (pic 1) and 3 #10 Allen screws. Put light duty threadlock on each screw. Pre install the clips to the panels leaving the screws loose   Fit the panel to the frame on the RZR. Turn the clamps so the curved edge is around the tubing. Tighten the screws. ==BE SURE NOT TO OVER TIGHTEN THEM.== See installed door (pic 2)
6. Put your seats back in, stand back and check out your new doors. We hope you will agree with us that these are the best looking and functioning door sets made!
7. After your 1ˢᵗ ride be sure to check the screws for tightness.

Call if you have any questions!

1

2

(instructions in color on our website. Go to 'tech' which is located to right of 'Shop by Make').