

X3 11 Lanyard Pin Kit Instructions

-Remove clutch cover

-Install one pin in each screw hole on the housing. Screw them in until you can no longer see the threads on the pin

-On the flat spot on the cover, mark your holes centered between two pins for drilling. You should use one rivet for two leashes. See picture below.



-Remove the cover, and using a 1/8" drill bit drill your holes

-Use a rivet gun to install 2 leashes per hole. Use provided washers on the back of the rivet so it does not pull through the plastic. (see pic above)