



1. Disconnect negative (-) battery cable.
2. Connect wiring as shown above
3. Mount gauge for easy viewing. Use spin lock ring (included) to mount to panel.
4. Snap gauge connector to wiring connector.
5. Reconnect negative battery cable.