




Instructions For Installing Upgraded Rhino Fuel Pump

1. Connect the lines and block off the second fuel outlet as shown below



2. When you bolt the new pump, you will use only one of the holes. You will also need to bend the rollover valve tab out slightly so it will fit.(see picture)

