



ALBA PRO ELITE RACE NERF BAR INSTRUCTIONS HONDA TRX450R

- 1) Remove left and right side foot peg and heelguard assemblies. Re-insert the fender stay bolt and tighten it. Save the foot peg allen bolts for re-use.

Pic 1:




- 2) Mount the foot peg mounts to the frame (see pic 1) Note that there is a "L" and an "R" stamped on each mount. "R" goes on the brake side, "L" on the shifter side. Note that the tube is not welded centered on the flat bar. When you bolt these on mount them so the welded tube is on the low side of the bracket (towards the ground). Use the original bolts with locktite on them. Tighten them.

Pic2:



- 3) Remove the forward lower motor mount bolt (#10 wrench) on each side. (see pic 2)
- 4) Mount the forward nerf bar mounts. (see pic 2) Use the provided short #8 bolts and spacers. Do not tighten yet.

Pic3:



- 5) Slide the nerf bar on each side. Line up the hole on the nerf bar under the foot peg with the hole in the nerf mount tube. Use the provided long #8 bolt and nylok nut. Tighten these (see pic 3) Tighten the 2 (each side) foot peg bolts and nuts –these pegs are adjustable – put them where you like them.
- 6) Now tighten both forward nerf bar bolts (1 each side). Tighten the allen bolt on the nerf bar clamp.
- 7) Install the nets following the picture below.



- 8) Re-check all bolts and nuts for tightness.
 - 9) After your first ride check all bolts and nuts for tightness.
-