



ALBA PROPEG NERF BAR INSTRUCTIONS --HONDA TRX 250R 1986 and 1987

You will need: drill, Loctite and hand tools.

- 1) Remove left and right side foot peg and heelguard assemblies. Using the stock bolts install Alba footpegs as shown in the picture. (use high strength Loctite). There will be an L for left and an R for right stamped on the back of each mount plate. Be sure to put the L peg on the left (shifter) side and the R on the right (brake side). Be sure the bolts are tight.




- 2) Install front mount as shown in picture. Use the supplied spacers between the mount and the frame. Use the supplied bolts. *Do not tighten the bolts yet.*



- 3) Slide the nerf bar on the footpeg and front mount as far as it will go. (see picture below) There is a hole thru the nerfbar tube under the footpeg. Mark this hole on the footpeg mount (both front and back holes). Take the nerf bar off and drill this hole to 5/16" (do this on both sides of the quad)
- 4) Re-install the nerf bars.
- 5) Install supplied bolt and nylok nut through the hole you drilled in each footpeg. Tighten the front mount bolt and the clamp that is on the nerfbar tube. *(There is a tab on the back of each nerf bar that is not used).*



- 6) Double check all hardware, making sure everything is tight. (Make sure to do this after your first ride and every few rides thereafter).
- 7) Install the nets following the picture below:



Please contact us @ support@albaracing.com or give us a call @ 619-562-0188 if you need any assistance.

TeamAlbaRacing.com 10806 Prospect Avenue, Santee CA 92071